

Installation guide for the Leyton & Stratford Cycle Shelters:

We recommend that concrete foundations should be laid to a minimum of 450mm x 450mm and to a minimum depth of 400mm for each upright support.

If you intend to install the shelter on a concrete plinth then we recommend the following:

- * The concrete base is a minimum of 500mm larger all round, than the footprint of the shelter.
- * The concrete base is a minimum of 200mm in thickness

Bolts Recommended (available in accessories)

- * Main Bay Bolts - 16 x 12mm bolts required
- * Extension Bolts - 8 x 12mm bolts required